

Foam Chamber Model-F

TECHNICAL DATA :

MODEL	F	
SIZE	50, 65, 80, 100 &150 NB inlet	
WORKING PRESSURE	Minimum 2.8 Kg. / sq. cm. (40 PSI) Maximum 7 Kg. / sq.cm.	
FLANGE CONNECTION	ANSI B16.5 Class 150#	
APPROXIMATE NET WEIGHT	F 50 - 28.0 Kg. F 65 - 40.0 Kg. F 80 - 58.0 Kg. F 100 - 86.0 Kg. F 150 - 118.0 Kg.	
VAPOUR SEAL RUPTURE PRESSURE	0.7 to 1.75 Kg./sq.cm. Running water/Water foam solution pressure at the inlet of Foam Chamber.	
MAXIMUM PERMISSIBLE BACK PRESSURE ON VAPOUR SEAL	0.06 Kg./sq.cm.	
FINISH	Red epoxy painted	
ORDERING INFORMATION	 a) Model and size b) Inlet pressure. c) Foam solution flow reqd. d) Inlet, outlet flange specification. e) Type of foam concentrate used. 	

APPLICATION

Foam Chamber is used in one of the most common application to protect vertical fixed roof (cone) liquid storage tanks, with or without internal floating roof with the low expansion foam system. The application of the foam is on the basis that the risk comprises the total surface area of the fuel. The foam system design guidelines generally used are in accordance with NFPA-11, standard.

Foam Chambers are defined by NFPA-11 as Type II discharge outlets for delivering the foam to the surface of a flammable liquid. The Foam Chambers are widely used with the In-line foam inductor, Balance pressure foam proportioning system, Bladder tank proportioner or Foam tender.



SPECIFICATION

Foam Chamber is an air aspirating foam discharge device, available in five sizes, covering wide range of flow from 75 to 3600 litres per minute at 3 to 7 kg/ sq.cm inlet pressure. The foam chamber contains a vapour seal to prevent the entry of vapour into the foam chamber and the foam solution pipe. Each foam chamber is supplied with an orifice plate, designed for the required flow and inlet pressure. The orifice is field replaceable in the event of change in design conditions. The foam is produced by introducing air into the foam solution stream. The inlet of foam chamber is designed to create venturi jet which draws air into the foam solution stream. The air is drawn into the foam solution through the holes located on the Foam chamber covered with stainless steel screen to exclude nesting birds and insects. The aerated foam is directed into the deflector for the gentle application of the expanded foam. The deflectors are available in different models.

The Foam Deflector is used with the Foam Chamber. The aerated foam from the Foam Chamber is directed in to the deflector for the gentle application of the expanded foam. The deflector reduces the expanded foam velocity and allows the foam to slide down the tank wall.

SYSTEM DESIGN REQUIREMENT

The NFPA-11, a standard for low expansion foam, has provided the essential requirement of an appropriate correctly designed foam pouring system, which are identified and outlined as following:

Foam Chamber Model-F

a) Number of Foam Chamber

The number of Foam Chambers required is determined by the tank diameter. Where two or more Foam Chambers are required, they shall be spaced equally around the tank periphery and each Foam Chamber shall be sized to deliver foam at an approximately same rate. Please refer graph to select the unit that will provide the required minimum foam solution application rate at the available operating pressure of the Foam Chamber. For minimum number of Foam Chamber requirement follow the recommendations as per NFPA/ OISD/TAC or as per the governmental codes or ordinances wherever applicable.

b) Minimum Foam Solution Application Rate

The minimum foam solution application rate is the rate at which the water and foam concentrate in correctly proportioned ratio should be delivered to the surface of a storage tank under protection to control and extinguish the fire. For minimum application rate requirement follow the recommendations as per NFPA/ OISD/TAC or governmental codes or ordinances wherever applicable

Testing And Maintenance

Qualified and trained person must commission the system. After few initial successful tests an authorized person must be trained to perform inspection and testing of the system. It is recommended to carry out physical inspection of the system regularly. The system must be fully tested at least once in a year or in accordance with applicable NFPA/OISD/TAC standards or in accordance to the standard of the organization having local jurisdiction.

Do not turn off the system or any valve to make repair or test the system, without placing a roving Fire Patrol in the area covered by the system. The Patrol should continue until the system is put back in service. Also inform the local security guard and control alarm station, so that avoid false alarm.

Each system is to be flushed properly. The vapour seal is to be replaced if the system has been operated. Normal testing of the chamber can be carried out by disconnecting the Foam Chamber from the tank and rotating it 180° and removing the vapour seal.

The air screen is to be inspected periodically for the obstruction of air inlet holes. If any obstruction is noticed, remove the same and flush, if necessary.

It is recommended to have regular maintenance programme to inspect the foam maker discharge area and deflector for possible deposits or obstruction.

NOTE

A PROVISION IS TO BE MADE FOR PRESSURE GAUGE MOUNTING AT INLET OF FOAM CHAMBER, WHICH CAN BE PLUGGED AFTER SUCCESSFUL COMMISSIONING OF THE SYSTEM. THIS WILL HELP TO ANALYSE THE SYSTEM WHILE COMMISSIONING.

Selection Of Foam Chamber (Model - F)

SIZE OF FOAM	K-FACTOR
CHAMBER	
50 NB	43.4 to 127
65 NB	115.4 to 254
80 NB	230.9 to 508
100 NB	461.8 to 1016
150 NB	923.6 to 1524.2

To select the size of the Foam Chamber use the following formula

Q=KWP

Q = Total solution flow in litres per minute.

- K = Constant for Foam Chamber
- P = Inlet pressure in kg/sq.cm.

Example

To find K-Factor Q = 300 LPM P = 3.5 Kg/sq.cm. K = 300 $\div \sqrt{3.5} = 160.35$

This K-Factor falls within the range of the Foam Chamber having 65 NB size. Hense 65 NB size Foam Chamber should be selected. The Foam Chamber size may also be selected with the help of the graph.

Example calculation

Tank type : Fixed roof storage tank Tank diameter : 40 meters. Foam concentrate to be used : AFFF 3% Pressure at inlet of Foam Chamber : 3.5 kg/sq.cm. Flash point of liquid stored in tank : - 27°C.

Surface area = πd^2 . $\div 4 = (3.14 \times 40^2) \div 4$ = 1257 Sq. mts.

a) Foam solution application rate

= *4.1 LPM /Sq. mts. X Surface area

- = 4.1 X 1257
- = 5154 LPM

*4.1 LPM is as per NFPA-11 (5 LPM as per OISD recommendations) or it should be as per prevailing rules of local authority having jurisdiction.

b) Number of Foam Chamber required for 40 metres diameter tank = 3 nos. minimum. (Ref.NFPA-11) Capacity of Foam Chamber required

> = 5154 ÷ 3 = 1718 LPM

The K-Factor for flow of 1718 LPM at 3.5 kg./sq.cm.

$$K = Q \div \sqrt{p} = 1718 \div \sqrt{3.5}$$

= 918.30

The K-Factor (918.30) falls within the K-Factor of 100 NB size of the Foam Chamber. Hence three numbers of 100 NB Foam Chamber with 1718 LPM capacity at 3.5 kg./sq.cm inlet pressure are to be selected.



Foam Chamber Model-F

Note

The above calculations are theoretical working. The system designer has to consider factor of safety in his working.

c) Foam Concentrate Requirement :

The fuel stored has flash point of 27°C. So the minimum system running duration required is 55 minutes. (Reference NFPA11)



The supplementary hose stream requirement is also to be considered and 100% reserve stock to be maintained or as per authority having jurisdiction.

The additional quantity of 5% is general guideline, however system designer has to work-out this percentage considering factor of safety, pipeline, minimum level for induction in storage tanks etc.

Note

- 1. It is recommended to select next higher size of Foam Chamber when the K-Factor is very much close to higher range of the model.
- 2. For the best performance the inlet pressure at the Foam Chamber should be 2.8 kg/sq.cm. or higher.

www.fireguard-uk.com

Foam Chamber



DIMENSION in millimetre (Approximate)

INLET (F1)	OUTLET (F2)	A	В	С
50 NB	80 NB	550	300	125
65 NB	100 NB	650	400	175
80 NB	150 NB	800	500	225
100 NB	200 NB	950	575	275
150 NB	250 NB	1100	650	325

 \measuredangle Dimension of inlet / outlet flanges (F1 / F2) are as per ANSI B16.5

Z Pipes used are ERW (Seamless Pipes are optional)

PART LIST

ITEM NO.	DESCRIPTION	ATERIAL SPECIFICATION
1	ORIFICE PLATE	S.S. 304
2	INLET FLANGE	STEEL A105
3	AERATING PIPE	STEEL PIPE
4	AIR STRAINER	S.S. 304
5	AIR STRAINER CAP	AL. ALLOY
6	AIR INLET PIPE	STEEL PIPE
7	VAPOUR SEAL CHAMBE	R STEEL PIPE
8	FOAM CHAMBER	STEEL PIPE
9	VAPOUR SEAL SEAT & F	RING STEEL
10	VAPOUR SEAL GASKET	NEOPRENE
11	VAPOUR SEAL	GLASS
12	WING NUT & STUD	S.S. 304
13	CHAMBER FLANGE	STEEL
14	GASKET	NEOPRENE
15	INSPECTION HATCH	STEEL
16	DISCHARGE PIPE	STEEL PIPE
17	OUTLET FLANGE	STEEL



Pressure Vs Flow Performance Characteristic



Typical Foam Chamber (Model-F) Installation With Deflector



APPLICATION

The Foam Deflector is used with the Foam Chamber. The aerated foam from the Foam Chamber is directed in to the deflector for the gentle application of the expanded foam. The deflector reduces the expanded foam velocity and allows the foam to slide down the tank wall.

Note : Above dimension are general guideline only. The system designer can adopt the dimensions as per NFPA/ TAC/OISD or as per the governing rules & ordinances having local jurisdiction.